

Doorking 9050 Manual



File Name: Doorking 9050 Manual.pdf

Size: 4337 KB

Type: PDF, ePub, eBook

Category: Book

Uploaded: 25 May 2019, 14:46 PM

Rating: 4.6/5 from 652 votes.

Status: AVAILABLE

Last checked: 16 Minutes ago!

In order to read or download Doorking 9050 Manual ebook, you need to create a FREE account.

[**Download Now!**](#)

eBook includes PDF, ePub and Kindle version

[Register a free 1 month Trial Account.](#)

[Download as many books as you like \(Personal use\)](#)

[Cancel the membership at any time if not satisfied.](#)

[Join Over 80000 Happy Readers](#)

Book Descriptions:

We have made it easy for you to find a PDF Ebooks without any digging. And by having access to our ebooks online or by storing it on your computer, you have convenient answers with Doorking 9050 Manual . To get started finding Doorking 9050 Manual , you are right to find our website which has a comprehensive collection of manuals listed.

Our library is the biggest of these that have literally hundreds of thousands of different products represented.



Book Descriptions:

Doorking 9050 Manual

Vehicular Slide Gate Operator. Use this manual for circuit board 4702010 Revision A or higher. DoDoReInglHzCircuit Board. Serial Number Phone Number. Leave Manual with Owner. Copyright 2013 DoorKing, Inc. All rights reserved. Copyright 2009 DoorKing, Inc. All rights reserved. Type of Gate. UL 325 Class I. Vehicular Slide Gates Only. Horsepower Current. Max Gate Weight Installed level. Max Gate Length Installed level Drive Sprocket Size. Cycles Per Hour Speed. Approximately 1 Ft. per Second. Entrapment Protection. Primary Inherent entrapment sensing system Type A. Secondary Provision for connection of a noncontact. Gate Frame. Use this manual for the Model 9050 Rev A or higher ONLY. Do not allow children to play in gate area Do not stand in gate path or walk through Read owner's manual and safety instructions. Chain Height. Idler wheels in Pad Concrete. Pad. DoorKing, Inc. reserves the right to make changes in the products described in this manual without notice and without obligation of DoorKing, Inc. Additionally, DoorKing, Inc. This manual is copyrighted, all rights Hard Shutdown Fail Secure Manual Release System Owner Installed. Emergency Vehicle Access Conditions Slide Gate Requirements. The operator is intended for installation only on gates used for vehicles. Pedestrians must be supplied with a separate Locate the gate such that Adjacent fence that covers open gate position. All openings of a horizontal slide gate are Closed Gate. Rollers. Gate Support Post. Note Install High Risk of Entrapment Area Screened Wire Mesh. Note A filler post or A contact sensor should A gap, measured in the horizontal plane parallel to Gate Frame. Gate Frame and Adjacent Fence Area Gates shall be designed, constructed and Guide Entrapment protection devices are required to reduce the risk of injury. Install sensors where the risk of entrapment or obstruction exists while See pages 2427 for Physical Stops. <http://www.adbagroup.com/E/88-yamaha-razz-manual.xml>

- **doorking 9050 manual, doorking 9050 manual, doorking 9050 manual, doorking 9050 manual pdf, doorking 9050 manual instructions, doorking 9050 manual downloads, doorking 9050 manual free, doorking 9050 manual software, doorking 9050 manual user, doorking 9050 manual transmission, doorking 9050 manual diagram, doorking 9050 manual.**

Positive stops shall be required Helps minimize the potential of entrapment during the back A filler post or Guide Rollers. Moving Gate Can Cause. Serious Injury or Death. See previous page for more information. KEEP CLEAR! Gate may move at any time Do not let children operate the gate or play This entrance is for vehicles only. Pedestrians must use separate entrance. Warning Signs. Separate. Pedestrian. Walkway Serious Injury or Death. Fence. Permanently mounted and easily Loop. Non Secure Side of Gate. Reverse. Loop. Closed Gate Secure Side of Gate. Automatic. Exit Loop. May be necessary on part See previous page for more Warning Sign Screened. Wire Mesh It can be installed on the High Risk of Entrapment Area. Non Contact Sensors Photo Sensors KEEP CLEAR! Gate may move at any time Do not let children operate the gate or play This entrance is for vehicles only. Pedestrians must use separate entrance. Physical Stop. Located so pedestrians Vehicular gates should be constructed and installed in accordance with ASTM F2200; Standard Specification for Automated. Vehicular Gate Construction. Important Safety Instructions. WARNING To reduce the risk of injury or death Keep the remote control away from children. The gate MUST reverse on contact with a rigid object or stop or reverse when an object After adjusting the force or the limit of travel, retest the gate operator. Failure to adjust Have a qualified service person make repairs to gate Pedestrians must use separate entrance. Pedestrians must be supplied with a separate Locate the gate such that Swinging gates should not open into public access areas. Activation of the reset control

shall notA wireless contact sensor shall functionImportant Notices. Vehicular gate operator products provide convenience and security. However, gate operators must use high levels of forceThese hazards may include. In addition to these potential hazards, automated vehicular gate systems must be installed in accordance with the UL

325.<http://diagcorlifescience.com/attachment/88-91-civic-service-manual.xml>

Safety Standard and the ASTM F2200 Construction Standard. Most lay persons are unaware of, or are not familiar with,Be sure that the installer has instructed you on the proper operation of the gate and gateBe sure that the installer has trained you about the basic functions of the required reversing systems associated with yourThese include reversing loops, inherent reversing system, electric edges,Keep it in a safe place for future reference.Install speed bumps and signs to keepFailure to adhere to posted speed limits can result inIf any of these devices areClass I. Class II. A vehicular gate operator or system intended for use in aA vehicular gate operator or system intended for use in aClass IV. A vehicular gate operator or system intended for use in aA vehicular gate operator or system intended for use in aThis table illustrates the entrapment protection requirements for each of the four UL 325 classes.Horizontal Slide, Vertical Lift, Vertical Pivot. Secondary Protection. Primary ProtectionA or C. A, B1, B2, C or D. Class III. A, B1 or B2. A, B1, B2, D or E. A, B1, B2 or C. Class IV. A, B1, B2 or D. A, B1, B2, C, D or E. Class I and II. Primary Protection. Swing and Vertical Barrier arm. A Inherent entrapment protection system. B1 Provision for connection of, or supplied with, a noncontact sensor photoelectric sensor or the equivalent. When used as the PRIMARY device, must be monitored. B2 Provision for connection of, or supplied with, a contact sensor edge device or the equivalent. C Inherent adjustable clutch or pressure relief device. D Provision for connection of, or supplied with, an actuating device requiring continuous pressure to maintainE An inherent audio alarm.

GATE A moving barrier such as a swinging, sliding, raising, lowering, or the like, barrier, that is a standalone passageRESTRICTED ACCESS VEHICULAR GATE OPERATOR CLASS IV A vehicular gate operator or system intended for use inVEHICULAR BARRIER ARM OPERATOR OR SYSTEM An operator or system that controls a cantilever type device orVEHICULAR HORIZONTAL SLIDEGATE OPERATOR OR SYSTEM A vehicular gate operator or system that controls aVEHICULAR SWINGGATE OPERATOR OR SYSTEM A vehicular gate operator or system that controls a gate whichSYSTEM In the context of these requirements, a system refers to a group of interacting devices intended to perform aWIRED CONTROL A control implemented in a form of fixed physical interconnections between the control, the associatedWIRELESS CONTROL A control implemented in means other than fixed physical interconnections such as radio waves orINHERENT ENTRAPMENT PROTECTION SYSTEM A system, examples being a motor current or speed sensing system,EXTERNAL ENTRAPMENT PROTECTION DEVICE A device, examples being an edge sensor, a photoelectric sensor, orENTRAPMENT The condition when an object is caught or held in a position that increases the risk of injury.This will help insure that your installation isThe proper installation of the vehicular slide gate operator is an extremely important and integral part of theCheck all local building ordinances and building codes prior to installingGood hardware is essential for proper operation of a sliding gate. DoorKing has a full line of gate hardware products that willThe gate must be properly installed and roll smoothly in both directions. Roller Bearing VWheelsGuide Rollers with. Protective Covers HelpsEndless Idler Assembly with. Protective Cover Helps toGate End Retainer Helps stabilizeThis can be theChain stops DO NOTGate End Retainer. Rubber bumper faces towardChain Stops. End. Post. GaThe Model 9050 operator is designed to be installed on these gate types.

<http://ninethreefox.com/?q=node/16026>

See the next 4 pages forIndividual installations and physical stops can vary.CaDoReadInc. Inglewood,Fro stopsChF rsDoReadInc. Inglewood,The Model 9050 operator is designed to be

installed in the front, rear, center or ceiling mounting positions shown on this page. Wheel Vrail ornamental gates are shown as examples but other gate types on the previous page can. Once the mounting position has been determined, the chain idler wheels may need to be. Physical stops MUST be used in the open AND close positions for ANY gate. Front Position with Concrete Pad. Standard method of installation. Chain Setup. Top View. Chain Idler. Wheels. Chain. Stop. A filler post or barrier may need to be. Front Position with Post Mount. Raises operator and allows different chain heights. Chain Setup. Gate End Retainer. Base Plate. Stop Bracket. Additional hardware required. Top View. Gate End Retainer. Gate End. Retainer. Hides the chain from outside the property looking in. Chain Setup. Chain Idler. Additional hardware required. A filler post or barrier may need to be. Top View. End Idler. See page 18 for. Rear Position with Post Mount. Hides the chain from outside the property looking in. Additional hardware required. Hides the chain from outside the property looking in. Setup. Chain Idler. Endless idler. Gate in Open Position. Gate End. End. A filler post or barrier may need to be. Note Chain stops CANNOT be used for this installation. End post with a gate end retainer must be installed as. Gate in Close Position. End Idler. See page 18 for. Can be mounted on the ceiling to conserve floor space. Ceiling. Chain Setup. Note There are NO fluids in the operator. Chain. A filler post or barrier may need to be. Operator. Bottom. Primary. Operator. Position. Secondary. Position. Loop Lead In Wires Low Voltage wire insulation. Concrete. AC Input Power High Voltage wire insulation. Sweeps. The conduit requirements for your application may vary from. Sweep. MUST be level. Lock. Electronic Box. Center. Underground depth of the. Concrete Pad.

Conduit. Post Mount with Conduit. Conduit. Conduit. Base Plate. Concrete Foundation. Base Plate. MUST be level. Note Weld the posts to the base plate and mount. Underground depth of the. Concrete Foundation. Pad, Post or Ceiling Mount Connected with Junction Boxes. All wire connections. Do not allow children to play in gate area. Operator MUST. Read owner's manual and safety instructions. Conduit. Low. Volt. Pad, post or. High. Volt. High. Volt. Never run high. Fail. Secure. Key Lock. Conduit Knock Out Sizes. Conduit. Prior to mounting the operator, be sure that the correct chain knockouts have been removed and chain idler wheels are in the. Fail. Secure Manual Release Kit Installation Note It is easier to install the 2600862 failsecure manual release kit before. Refer to the instruction sheet supplied with the kit for installation. Positioning Operator and Chain Brackets. Chain. Bracket. Lines up. Wheels. Chain Idler. Wheels. Operator NOT. Chain brackets. Correct. Height. Frame. Correct. Height. Chain Bracket. Attaching Operator. Door. King recommends a. Chain bracket. Op. Connect Chain Bracket. Op. Nut. Make ink. Connect Chain to Chain Bracket. Lock. Washer. Washers. Connect chain to chain bolt with. Do not over tighten the chain. Make sure the endless idler assembly is securely fastened to the wall or post. Depending on which type of installation will be. Center and Rear Mount Positions. Top View. Operator. Idler Wheel. Lower chain MUST. Chain Brackets. Idler. Center Mount Position. Side View. Operator. Idler Wheel. Lower chain does NOT align with upper chain. Note Be sure that the chain is aligned and. Installing the chain in any. Lower Chain. Lower chain. Chain. Return. Bracket. Lower chain MUST be. Idler. Lower chain mounted. Too Low. Gate Rail. Rear Mount Position. Side View. Operator. Idler. Wheels. Lower Chain. Return. Endless. Idler. Lower chain. Upper and lower chain. MUST be the same. Lower chain mounted. Too Low. This. Door. King Slide Gate Operator is shipped with two warning signs.

The purpose of the warning. See page 5 for suggested mounting positions of signs. It is recommended that a. Since building codes vary from city to city, we highly recommend that you check with your local building department prior. If power wiring is greater than the maximum distance shown, it is. Never run low voltage rated wire insulation in the. When large gauge wire. Dual 9050's, Single Power Source. Dual Operators. AC Power. AC Power. DO NOT power up and cycle the. Damage could occur to. Use the wire restrainers inside. MOV. Helps. AC Power Terminal. Hot. Neu. Chassis. Ground. White Neutral. Black 115 VAC Hot. Green Chassis. High Voltage. AC Power Wire. External Power. Disconnect Switch. A separate power disconnect. Conduit. Every time the operator is powered up, the

First open command will automatically run "Multiple Every time the operator is powered up, the First open command will Loop Detector See page 27. Exit Loop Port. Reverse Loop Port Page 24 Normally Closed NC operation See next page and page 28. Self Test Mode. Do not run self test with Self Test Mode Normal Mode Rev H. See switch setting DIP Switch options. DIP Switches. Typical setting shown. Single Channel LEDs will blink as Inherent Reverse Sensor. Adjust reversing sensitivity. Full counter clockwise for Min Max. Sensitivity The DIP switches located on the circuit board are used to program the operator to operate in various modes and to turn on or Whenever a switch setting is changed, power to the operator must be turned OFF and then turned Check and review ALL switch settings prior to applying power to the operator. Every time the operator is powered up, the First open command will automatically run "Multiple Switch. Function. Setting. Description. Front Mount Timer Solenoid Lock. Opening Opening Center or. Mounts. Opening Opens All Rear. All Rear. Left. Right Opens OFF Autoclose timer is OFF. Manual input required to close gate. ON Autoclose timer is ON. Adjustable from 123 seconds to close gate. OFF Relay is activated when gate is full open.

ON Relay is activated when gate is not closed. OFF Normal Setting. Fail Safe Factory Set. Lock engages only when an attempt is ON Fail Secure. Lock engages after each cycle. CAUTION Do not use this setting unless Gate Open. Back Off. Position Gate stops short 1" from full open position. Used for a reversing edge device. Gate stops short 2" from full open position. Gate stops short 3" from full open position. Used for a reversing edge device. Gate Close. Position Gate stops short 1" from full close position. Gate stops short 2" from full close position. Gate stops short 3" from full close position. Switch 1 Must OPEN the gate upon initial AC power up and open command. If the first open command begins to close the gate, Opening direction will vary depending on the chain setup position See above. Switch 2 Turns the autoclose timer on or off. Can be adjusted from 1 to 23 seconds to close gate. Switch 3 This switch determines when the relay on the board will be activated. This relay can be used as a switch for various Switch 4 This switch determines the operation of the built in solenoid lock. The OFF setting is the factory setup. Caution Do not Changing this See pages 33 and 34 for more information Switches 56 These work in conjunction with each other and determine if the operator will stop the gate at the full open Needed only when using a reversing edge Switches 78 These work in conjunction with each other and determine if the operator will stop the gate at the full close Needed only when using a reversing edge These positions are determined by the physical stops that have been installed See section 1.2, page 10. Timer The Auto Close Timer should be turned ON DIP Switch 2 to allow the "multiple gate cycles" to run automatically, Clutch The clutch's factory setting will work correctly for most installations.

The clutch must NOT slip while the gate is cycling If the clutch slips during this period, it must be Safety Devices Run this sequence before testing any safety features primary inherent reverse sensor, secondary entrapment Reversing Edge mounted on the Gate using End Posts When using a reversing edge on either end of the gate with an end Sequence of Automatic "Multiple Gate Cycles" to Set Gate Limits. CAUTION Keep pedestrians and vehicles clear of the gate while this sequence is running! After the first open command is given to the operator gate can be in any position Open. Gate MUST open until it contacts the physical "open" stop. if gate starts to close, turn power off and Turn power back on and give open command again. Close Autoclose timer will close the gate until it contacts the physical "close" stop. Manual close command Open. Gate will automatically open until it gets approximately 12 inches away from the full open position and Autoclose timer will close the gate until it gets approximately 12 inches away from the full close position. Close and stop, then continue closing until it contacts the physical "close" stop again. Manual close command Sequence. Finished. Open and close gate positions are now set and will be remembered by the operator until it loses AC power. Gate will function normally after automatic "Multiple Gate Cycles" sequence has finished. Note If gate encounters an obstruction during this sequencing, In addition to the inherent reverse sensor, this operator is equipped with a mechanical slip clutch UL 325 Type C to further

reduce the DO NOT over tighten the clutch to compensate for a gate that is damaged, poorly constructed. Ideal Clutch Adjustment The operator will cycle the gate without the clutch slipping. The clutch to adjust clutch. Note After power has been turned back on, the first open command will Hex Bolt. Test the operator clutch adjustment. Magnetic. Spring Assembly. Hex nut is connected to black plastic magnet holder.

Important Note 2 magnetic sensors located on the bottom of. Keep all high voltage wires away from. CAUTION Keep pedestrians and vehicles clear of the gate while. Place an immobile object along the gate path, allowing the gate to strike. The clutch must slip and the gate. If it does not, readjust. This vehicular gate operator is equipped with an inherent adjustable reversing sensor Type A used as the primary entrapment protection. The gate will reverse direction after "physically" encountering an obstruction in either. If the AutoClose Timer DIPswitch 2 is ON and the gate physically encounters an obstruction during the CLOSING cycle, it will reverse. Another input command is needed before the gate will reset. For the reverse system to function correctly, the gate must be properly installed and work freely in both directions. The clutch must be. Min Max. Sensitivity. Note Each operator must be individually. Test the operator reversing sensitivity. Place an immobile object along the gate path, allowing the gate to strike it while in the open and close cycles. The gate must reverse direction. If it does not, increase the reverse sensitivity step 2 and repeat this test until the correct sensitivity has been set. The. In addition to the inherent reversing sensor system, the Model 9050 has a 6pin UL 325 terminal for the connection of photo sensors. Type B1. Entrapment protection devices must. Install these devices where the risk of entrapment or obstruction exists while the gate is moving. The Model 9050 offers numerous options to meet your specific needs. The next 2 pages show wiring and typical positioning of the entrapment. Outlets. Rea. All inputs are normally open. NO. Gate will resume the open cycle. Do. Do. Inc. CLOSE Entrapment Sensor. OPEN Contact Sensor. CLOSE Contact Sensor. Alarm Reset. Entrapment Alarm. Closed Gate. Opening. Direction Photo Beam. Entrapment Area. Entrapment Area. Gate will resume the close cycle. Closing. Direction Photo Beam. Closed Gate. Filler Post if necessary.

Closed Gate. Note If the gate is. Opening. Direction Reversing Edges. Gate Support Post if Installed. Entrapment Area. Entrapment Area. Closing. Direction Reverse Edge. Closed Gate. Factory wired. Entrapment Alarm This is an output from the circuit board that drives the entrapment alarm. Do not connect any other device to this terminal. Factory wired. Typical UL Photo Sensor mounting height. If the distance between the gate. Secure Side. NonSecure Side. Inside Property. Outside Property. Less. Less. Filler Post or Barrier. Reversing Edge Open Contact Sensor. UL sensor mounted on wall. UL sensor mounted on post. Note Additional. Wall. No higher than. Photo sensors may be installed on either side of gate frame, as close as. A filler post or barrier may need to be installed between the. A reversing edge should be installed on the post or barrier. Photo Sensors With Filler Post and Reverse Edge Sample Setup. Closing. Direction Photo Beam. Wall. Filler Post with Opening. Direction Reversing Edge If necessary, see above. Closing. direction photo sensors wired to UL 325 terminal. Normally Open. Main. Terminal. Common. Normally Open.

<http://www.raumboerse-luzern.ch/mieten/cycore-effects-manual>